





Owner's Manual

Original Instructions INVERTER Air Conditioners

Air-to-water Heat Pump

GRS-CQ4.0Pd/NhG3-E	GRS-CQ4.0Pd/NhG4-E
GRS-CQ6.0Pd/NhG3-E	GRS-CQ6.0Pd/NhG4-E
GRS-CQ8.0Pd/NhG3-E	GRS-CQ8.0Pd/NhG4-E
GRS-CQ10Pd/NhG3-E	GRS-CQ10Pd/NhG4-E
GRS-CQ8.0Pd/NhG3-M	GRS-CQ8.0Pd/NhG4-M
GRS-CQ10Pd/NhG3-M	GRS-CQ10Pd/NhG4-M
GRS-CQ12Pd/NhG3-E	GRS-CQ12Pd/NhG4-E
GRS-CQ14Pd/NhG3-E	GRS-CQ14Pd/NhG4-E
GRS-CQ16Pd/NhG3-E	GRS-CQ16Pd/NhG4-E
GRS-CQ12Pd/NhG3-M	GRS-CQ12Pd/NhG4-M
GRS-CQ14Pd/NhG3-M	GRS-CQ14Pd/NhG4-M
GRS-CQ16Pd/NhG3-M	GRS-CQ16Pd/NhG4-M
GRS-CQ8.0Pd/NhG3-E1	GRS-CQ8.0Pd/NhG4-E1

Thank you for choosing commercial air conditioners. Please read this Owner's Manual carefully before operation and retain it for future reference.

If you have lost the Owner's Manual, please contact the local agent or visit www.gree.com or send an email to global@cn.gree.comfor the electronic version.

GREE ELECTRIC APPLIANCES, INC. OF ZHUHAI

To Users

Thank you for selecting this product. Please read this instruction manual carefully before installing and using the product, so as to master and correctly use the product. In order to guide you to correctly install and use our product and achieve expected operating effect, we hereby instruct as below:

- (1) This equipment should be installed, operated or maintained by the qualified servicemen who have had specific training. During operation, all safety issues covered in the labels, User's Manual and other literature should be followed strictly. This equipment is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.
- (2) This product has gone through strict inspection and operational test before leaving the factory. In order to avoid damage due to improper disassembly and inspection, which may impact the normal operation of unit, please do not disassemble the unit by yourself. You can contact our designated dealer or local service center for professional support if necessary.
- (3) When the product is faulted and cannot be operated, please contact our designated dealer or local service center as soon as possible by providing the following information..
 - Contents of nameplate of product (model, cooling/heating capacity, product No., ex-factory date).
 - Malfunction status (specify the situations before and after the error occurs).
- (4) All the illustrations and information in the instruction manual are only for reference. In order to make the product better, we will continuously conduct improvement and innovation without further notice.

Contents

Safety Notices (Please be sure to abide)	1
1. Diagram of the Operating Principle	10
2. Operating Principle of the Unit	10
3. Nomenclature	12
5. Main Components	15
6. Installation Guideline of Monobloc Unit	16
6.1 Instruction to installation	16
6.2 Installation of monobloc unit	16
7. Installation of Hydraulic Unit	20
7.1 Available external static pressure of outlet	20
7.2 Ambient temperature and leaving water temperature upper limit	23
7.3 Water volume and expansion vessel pressure	24
7.4 The method of calculating the charging pressure of expansion vessel	25
7.5 Selection of expansion vessel	26
8. Remote Air Temperature Sensor	27
9. Thermostat	28
10. 2-Way Valve	28
11. 3-Way Valve	29
12. Other Thermal	30
13. Optional Electric Heater	31
14. Gate-controller	32
15. Charging and Discharging of Refrigerant	32
16. Requirements on Water Quality	34
17. Electric Wiring	34
17.1 Wiring principle	34
17.2 Specification of power supply wire and leakage switch	35
17.3 Wiring of Control boards	36
17.4 Electric wiring of terminal boards	45
18. Commissioning	49
18.1 Check before startup	49
18.2 Test run	50
19. Daily Operation and Maintenance	50
19.1 Recovery	52
19.2 Decommissioning	52

19.3 Notice before seasonal use	53
19.4 Error Codes	53



Safety Notices (Please be sure to abide)

WARNING: If not abide strictly, it may cause severe damage to the unit or the people.

NOTE: If not abide strictly, it may cause slight or medium damage to the unit or the people.

This sign indicates that the operation must be prohibited. Improper operation may cause severe damage or death to people

This sign indicates that the items must be observed. Improper operation may cause damage to people or property.

№ NOTE

After receipt of the unit, check it for appearance, unit model compared with your desire and attachments.

Design and installation work of the unit must be performed by authorized personnel according to applicable laws and regulations and this Instruction.

After installation work, the unit cannot be energized unless there is not any problem in check.

Ensure periodical clean and maintenance of the unit after normal operation of the unit for longer life and reliable operation.

If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

The appliance shall be installed in accordance with national wiring regulations.

This product is a kind of comfort air conditioning, and is not allowed to be installed where there are corrosive, explosive and inflammable substances or smog; otherwise it would lead to operation failure, shortened service life, five hazard or even severe injuries. Special air conditions are required for where mentioned above.



Correct Disposure

This marking indicates that this product should not be disposed with other household wastes throughout the EU.To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To retuern your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

R32:675



⚠ WARNING

Once abnormality likeburning smell occurs, please cut off the power supply immediately and then contact with service center.





If the abnormality still exists, the unit may be damaged and electric shock or fire may result. Don't operate the unit with wet hand.



Otherwise, it may cause electric shock.

Before installation, please see if the voltage of local place accords with that on nameplate of unit and capacity of power supply, power cord or socket is suitable for input power of this unit.



Special circuit must be adopted for power supply to prevent fire.



Do not use octopus multipurpose plug or mobile terminal board for wire connection.

Be sure to pull out the power plug and drain the indoor unit and water tank when unit is not in use for a long time.





Never damage the electric wire or use the one which is not specified.





Otherwise, it may cause overheating or fire.

Before cleaning please cut off the power supply.



Otherwise, it may cause electric shock or damage.

The power supply must adopt special circuit with leakage switch and enough capacity.

User can not change power cord socket without prior consent. Wiring working must be done by professionals. Ensure good earthing and don't change earthing mode of unit.




Earthing: the unit must be earthed reliably! The earthing wire should connect with special device of buildings.



If not, please ask the qualified personnel to install.

Furthermore, don't connect earth wire to gas pipe, water pipe, drainage pipe or any other improper places which professional does not recognize. Never insert any foreign matter into outdoor unit to avoid damage. And never insert your hands into the air outlet of outdoor unit.



Don't attempt to repair the unit by yourself.



Improper repair may cause electric shock or fire, so you should contact the service center to repair.

Don't step on the top of the unit or place anything on it.



There is the danger of fall of things or people.

Never block the air inlet and outlet of unit.



It may reduce efficiency or cause stop of the unit and even fire.

Keep pressurized spray, gas holder and so on away from the unit above 1m.



It may cause fire or explosion.



Please note whether the installation stand is firm enough or not.



If damaged, it may cause fall of the unit and injury of people.

Unit should be installed at the place with good ventilation to save energy.

When there is not water in water tank, never power the unit on to run.



Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacturer. Should repair be necessary, contact your nearest authorized service centre. Any repairs carried out by unqualified personnel may be dangerous. The appliance shall be stored in a room without continuous operating ignition sources. (for example: open flames, an operating gas appliance or an operating electric heater.) Do not pierce or burn.

Appliance filled with flammable gas R32. For repairs, strictly follow manufacturer's instructions only. Be aware that refrigrants not contain odour. Read specialist's manual.

If a stationary appliance is not fitted with a supply cord and a plug, or with other means for disconnection from the supply mains having a contact separation in all poles that provides full disconnection under overvoltage category III conditions, the instructions shall state that means for disconnection must be incorporated in the fixed wiring in accordance with the wiring rules.

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

This appliance shall not be installed indoor and shall be installed in a well-ventilated oudoor area.

The appliance shall be stored so as to prevent mechanical damage from occurring.



∧ NOTE



Appliance filled with flammable gas R32.



Before use the appliance, read the owner's manual first.

To realize the function of the air conditioner unit, a special refrigerant circulates in the system. The used refrigerant is the fluoride R32, which is specially cleaned. The refrigerant is flammable and inodorous. Furthermore, it can leads to explosion under certain conditions. But the flammability of the refrigerant is very low. It can be ignited only by fire.

Compared to common refrigerants, R32 is a nonpolluting refrigerant with no harm to the ozonosphere. The influence upon the greenhouse effect is also lower. R32 has got very good thermodynamic features which lead to a really high energy efficiency. The units therefore need a less filling.

Before installation, please check if the adopted power is accordance with that listed on nameplate, and check the safety of power.

The unit shall contact with the supply mains by a full disconnection device under overvoltage category $\, {
m III} \, .$

Before using, please check and confirm if wires and water pipes are connected correctly to avoid water leakage, electric shock or fire etc.

Don't operate the unit with wet hand, and don't allow children to operate the unit.

The On/off in the instruction is for the operation to on and off button of PCB for users; cut off power means to stop supplying power to the unit.

Don't directly expose the unit under the corrosive ambient with water or dampness.

Don't operate the unit without water in water tank .The air outlet/inlet of unit cannot be blocked by other objects.

The water in unit and pipeline should be discharged if the unit is not in use, to prevent the water tank, pipe line and water pump from frost-cracking.

Never press the button with sharp objects to protect manual controller. Never use other wires instead of special communication line of the unit to protect control elements. Never clean the manual controller with benzene, thinner or chemical cloth to avoid fading of surface and failure of elements. Clean the unit with the cloth soaked in neutral eradicator. Slightly clean the display screen and connecting parts to avoid fading.

The power cord must be separated with the communication line.

Any person who is involved with working on or breaking into a refrigerant circuit should hold a current valid certificate from an industry-accredited assessment authority, which authorises their competence to handle refrigerants safely in accordance with an industry recognised assessment specification.

Servicing shall only be performed as recommended by the equipment manufacturer. Maintenance and repair requiring the assistance of other skilled personnel shall be carried out under the supervision of the person competent in the use of flammable refrigerants.



Maximum and minimum water operating temperatures

Maximum					
Item	Minimum water operating temperatures	Maximum water operating temperatures			
Cooling	5°C	25°C			
Heating	20°C	65°C*			
Water heating	40°C	80°C**			

Maximum and minimum water operating pressures

Item	Minimum water operating pressures	Maximum water operating pressures	
Cooling			
Heating	0.05MPa	0.25MPa	
Water heating			

Maximum and minimum entering water pressures.

Item	Minimum entering water pressures	Maximum entering water pressures
Cooling		
Heating	0.05MPa	0.25MPa
Water heating		

^{*:} The leaving water temperature varies at different environment. 65°C is the highest leaving water temperature at 10-20°C ambient temperature.

The range of external static pressures at which the appliance was tested (add-on heat pumps, and appliances with supplementary heaters, only); If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

The appliance is intended to be permanently connected to the water mains and not connected by a hose-set.

If there is any question, please contact with local dealer, authorized service center, agencies or our company directly.

^{**:} When the electric heater for the water tank prepared by the user themselves has been activated, the leaving water temperature can go up to 80°C.



⚠ NOTE

If any hot work is to be conducted on the refrigeration equipment or any associated parts, appropriate fire extinguishing equipment shall be available to hand. Have a dry powder or CO₂ fire extinguisher adjacent to the charging area.

Where electrical components are being changed, they shall be fit for the purpose and to the correct specification. At all times the manufacturer's maintenance and service guidelines shall be followed. If in doubt consult the manufacturer's technical department for assistance.

The following checks shall be applied to installations using flammable refrigerants:

- the charge size is in accordance with the room size within which the refrigerant containing parts are installed;
- the ventilation machinery and outlets are operating adequately and are not obstructed;
- if an indirect refrigerating circuit is being used, the secondary circuit shall be checked for the presence of refrigerant;
- marking to the equipment continues to be visible and legible. Markings and signs that are illegible shall be corrected;
- refrigeration pipe or components are installed in a position where they are unlikely to be exposed to any substance which may corrode refrigerant containing components, unless the components are constructed of materials which are inherently resistant to being corroded or are suitably protected against being so corroded.

Repair and maintenance to electrical components shall include initial safety checks and component inspection procedures. If a fault exists that could compromise safety, then no electrical supply shall be connected to the circuit until it is satisfactorily dealt with. If the fault cannot be corrected immediately but it is necessary to continue operation, an adequate temporary solution shall be used. This shall be reported to the owner of the equipment so all parties are advised.

Initial safety checks shall include: that capacitors are discharged: this shall be done in a safe manner to avoid possibility of sparking; that no live electrical components and wiring are exposed whiule charging, recovering or purging the system; that there is continuity of earth bonding.



During repairs to sealed components, all electrical supplies shall be disconnected from the equipment being worked upon prior to any removal of sealed covers, etc. If it is absolutely necessary to have an electrical supply to equipment during servicing, then a permanently operating form of leak detection shall be located at the most critical point to warn of a potentially hazardous situation.

Particular attention shall be paid to the following to ensure that by working on electrical components, the casing is not altered in such a way that the level of protection is affected. This shall include damage to cables, excessive number of connections, terminals not made to original specification, damage to seals, incorrect fitting of glands, etc.

Ensure that apparatus is mounted securely.

Ensure that seals or sealing materials have not degraded such that they no longer serve the purpose of preventing the ingress of flammable atmospheres. Replacement parts shall be in accordance with the manufacturer's specifications.

NOTE The use of silicon sealant may inhibit the effectiveness of some types of leak detection equipment.

Intrinsically safe components do not have to be isolated prior to working on them.

Do not apply any permanent inductive or capacitance loads to the circuit without ensuring that this will not exceed the permissible voltage and current permitted for the equipment in use.

Intrinsically safe components are the only types that can be worked on while live in the presence of a flammable atmosphere. The test apparatus shall be at the correct rating.

Replace components only with parts specified by the manufacturer. Other parts may result in the ignition of refrigerant in the atmosphere from a leak.


Check that cabling will not be subject to wear, corrosion, excessive pressure, vibration, sharp edges or any other adverse environmental effects. The check shall also take into account the effects of ageing or continual vibration from sources such as compressors or fans.

Under no circumstances shall potential sources of ignition be used in the searching for or detection of refrigerant leaks. A halide torch (or any other detector using a naked flame) shall not be used.

Equipment shall be labelled stating that it has been de-commissioned and emptied of refrigerant. The label shall be dated and signed. Ensure that there are labels on the equipment stating the equipment contains flammable refrigerant



1. Diagram of the Operating Principle



Item	Description	Item	Description
1	Compressor	11	High pressure switch
2	4-Way Valve	12	Filter
3	Air side heat exchange	13	Electric heater
4	EXV1	14	Expansion valve
5	EXV2	15	Water pump
6	Economizer	16	Water flow switch
7	Plate-type heat exchanger	17	Safety valve
8	Gas-liquid separator	18	Low pressure switch for heating
9	Dryer	19	Low pressure switch for cooling
10	High pressure transducer		

Note: it is the system schematic diagram. The manufacturer is committed to continuously improving this product to ensure the highest quality and reliability standards and to meet local regulations and market requirements. All features and specifications are subject to change without prior notice.

2. Operating Principle of the Unit

DC Inverter Air to Water Heat Pump is composed of outdoor unit, indoor unit and internal-fan coil water tank. Operation functions:

Item	Function	Item	Function
1	Cooling	9	Forced operation mode
2	Heating	10	Quiet mode;
3	Water heating	11	Disinfection mode
4	Cooling +water heating	12	Weather-dependent operation;
5	Heating+ water heating	13	Floor debugging
6	Emergency mode	14	Air removal of the water system
7	Fast hot water	15	Other thermal
8	Holiday mode		

(1) Cooling: in cooling mode, the refrigerant is condensed in the outdoor unit and evaporated in the indoor unit. Via the heat exchange with water in the indoor unit, the temperature of water decreases and it releases heat while the refrigerant absorbs heat and evaporates. With the help of wired controller, the outflow temperature can meet the user's requirement. Through the control of valve, the low-temperature water in the system is connected with indoor fan coil and underground pipe, and exchanges heat with the indoor air so that the indoor temperature decreases to the required range.



- (2) Heating: in heating mode, the refrigerant evaporates in the outdoor unit and is condensed in the indoor unit. Via the heat exchange with water in the indoor unit, the water absorbs heat and its temperature increases while the refrigerant releases heat and is condensed. With the help of wired controller, the outflow temperature can meet the user's requirement. Through the control of valve, the high-temperature water in the system is connected with indoor fan coil and underground pipe, and exchanges heat with the indoor air so that the indoor temperature increases to the required range.
- (3) Water heating: in water heating mode: the refrigerant evaporates in the outdoor unit and is condensed in the indoor unit. Via the heat exchange with water in the indoor unit, the water absorbs heat and its temperature increase while the refrigerant releases heat and is condensed. With the help of wired controller, the outflow temperature can meet the user's requirement. Through the control of valve, the high-temperature water in the system is connected with the coil pipe of bearing water tank, and exchanges heat with the water in the water tank so that the temperature of water tank increases to the required range.
- (4) Cooling + water heating: when cooling mode exists together with the water heating mode, the user can set the priority of these two modes based on the needs. The default priority is heat pump. That is under the default setting, if cooling mode exists together with the water heating mode, the heat pump gives priority to cooling. In that case, water heating can only realized with e-heater of the water tank. Inversely, the heat pump gives priority to water heating and switches to cooling after finishing water heating.
- (5) Heating+ water heating: when heating mode exists together with the water heating mode, the user can set the priority of these two modes based on the needs. The default priority is heat pump. That is under the default setting, if heating mode exists together with the water heating mode, the heat pump gives priority to heating. In that case, water heating can only realized with e-heater of the water tank. Inversely, the heat pump gives priority to water heating and switches to heating after finishing water heating.
- **(6) Emergency mode:** this mode is only available for heating and water heating. When the outdoor unit stops due to malfunction, enter the corresponding emergency mode; as to heating mode, after entering the emergency mode, heating can only be realized through e-heater of the indoor unit. When the setting outflow temperature or indoor temperature is reached, the e-heater of indoor unit will stop running; as to water heating mode, the e-heater of indoor unit stops while the e-heater of water tank runs. When the setting temperature or water tank is reached, the e-heater will stop running.
- (7) Fast hot water: at the fast hot water mode, the unit runs according to the water heating control of heat pump and the e-heater of water tank runs at the same time.
- (8) Holiday mode: this mode is only available for heating mode. This mode is set to keep indoor temperature or leaving water temperature in a certain range, so as to prevent water system of the unit from freezing or protect certain indoor articles from freezing damage. When the outdoor unit stops due to malfunction, the two e-heaters of the unit will run.
 - (9) Forced operation mode: this mode is only used for refrigerant recovery and debugging for the unit.
- (10) Quiet mode: Quiet mode is available in cooling, heating and water heating mode. At the quiet mode, the outdoor unit will reduce the running noise via automatic control.
- (11) Disinfection mode: in this mode, the water heating system can be disinfected. When starting up the disinfection function and setting corresponding time to meet the requirement of disinfection mode, the function will start. After the setting temperature is reached, this mode will terminate.
- (12) Weather-dependent operation: this mode is only available for space heating or space cooling. In Weather-dependent mode, the setting value (remote room air temperature or leaving water temperature) is detected and contolled automatically when the outdoor air temperature is changed.
 - (13) Floor commissioning: this function is intended to preheat the floor periodically for the initial use.
- (14)Air removal of the water system: this function is intended to replenish water and remove air in the water system to make the equipment run at the stabilized water pressure.
- (15)Other thermal: when the outdoor temperature is lower than the set point for starting other thermal and the unit is under the error condition and the compressor has stopped for three minutes, the other thermal will start to supply heat or hot water to the room.



3. Nomenclature

G	RS	-	С	Q	16	Pd	1	Nh	G	-	M
1	2		3	4	5	6		7	8		9

NO.	Description	Options
1	GREE	G-GREE Air to water heat pump
2	Heat Pump Water Heater	RS
3	Heating Mode	S= Static; C=Circulating
4	Function	Q=Multi-function; Omit=Single-function
5	Nominal Heating Capacity	4.0=4.0kW; 6.0=6.0kW; 8.0=8.0kW; 10=10kW; 12=12kW; 14=14kW; 16=16kW
6	Compressor Style	Pd=DC Inverter; Omit=On/Off
7	Refrigerant	Na=R410A; Nh=R32
8	Design Serial Number	G3,G4, G4 series is the same with G3 series but without the electric heater.
9	Power Supply	E/E1=230V,~,50Hz;M=400V,3N~,50Hz

Model Line-Up

Model Lille-op				
Model	Heating*, kW	Power Input, kW	COP, W/W	Power supply
GRS-CQ4.0Pd/NhG3-E	5.00	0.926	5.40	
GRS-CQ6.0Pd/NhG3-E	6.00	1.111	5.40	
GRS-CQ8.0Pd/NhG3-E	8.20	1.54	5.32	
GRS-CQ8.0Pd/NhG3-E1	8.00	1.63	4.91	
GRS-CQ10Pd/NhG3-E	10.20	2.02	5.05	230VAC,1Ph,50Hz
GRS-CQ12Pd/NhG3-E	12.0	2.43	4.94	200 770, 11 11,001 12
GRS-CQ14Pd/NhG3-E	14.2	2.99	4.75	
GRS-CQ16Pd/NhG3-E	15.7	3.45	4.55	
GRS-CQ8.0Pd/NhG3-M	8.20	1.62	5.06	
GRS-CQ10Pd/NhG3-M	10.20	2.06	4.95	
GRS-CQ12Pd/NhG3-M	12.0	2.49	4.82	
GRS-CQ14Pd/NhG3-M	14.2	3.09	4.60	400VAC,3Ph,50Hz
GRS-CQ16Pd/NhG3-M	15.7	3.57	4.40	
GRS-CQ4.0Pd/NhG4-E	5.00	0.926	5.40	
GRS-CQ6.0Pd/NhG4-E	6.00	1.111	5.40	
GRS-CQ8.0Pd/NhG4-E	8.20	1.54	5.32	
GRS-CQ8.0Pd/NhG4-E1	8.00	1.63	4.91	
GRS-CQ10Pd/NhG4-E	10.20	2.02	5.05	230VAC,1Ph,50Hz
GRS-CQ12Pd/NhG4-E	12.0	2.43	4.94	
GRS-CQ14Pd/NhG4-E	14.2	2.99	4.75	
GRS-CQ16Pd/NhG4-E	15.7	3.45	4.55	
GRS-CQ8.0Pd/NhG4-M	8.20	1.62	5.06	
GRS-CQ10Pd/NhG4-M	10.20	2.06	4.95	
GRS-CQ12Pd/NhG4-M	12.0	2.49	4.82	
GRS-CQ14Pd/NhG4-M	14.2	3.09	4.60	400VAC,3Ph,50Hz
GRS-CQ16Pd/NhG4-M	15.7	3.57	4.40	



Model	Cooling** ,kW	Power Input, kW	EER, W/W	Power supply
GRS-CQ4.0Pd/NhG3-E	5.00	0.962	5.20	
GRS-CQ6.0Pd/NhG3-E	6.50	1.275	5.10	
GRS-CQ8.0Pd/NhG3-E	8.30	1.56	5.32	
GRS-CQ8.0Pd/NhG3-E1	8.00	1.65	4.85	
GRS-CQ10Pd/NhG3-E	10.2	2.00	5.10	230VAC,1Ph,50Hz
GRS-CQ12Pd/NhG3-E	12.0	2.45	4.90	
GRS-CQ14Pd/NhG3-E	13.7	3.00	4.57	
GRS-CQ16Pd/NhG3-E	15.5	3.60	4.31	
GRS-CQ8.0Pd/NhG3-M	8.30	1.64	5.06	
GRS-CQ10Pd/NhG3-M	10.20	2.13	4.79	
GRS-CQ12Pd/NhG3-M	12.0	2.61	4.60	400VAC,3Ph,50Hz
GRS-CQ14Pd/NhG3-M	13.9	3.32	4.19	400 VAO, 31 11, 30112
GRS-CQ16Pd/NhG3-M	15.4	4.05	3.80	
GRS-CQ4.0Pd/NhG4-E	5.00	0.962	5.20	
GRS-CQ6.0Pd/NhG4-E	6.50	1.275	5.10	
GRS-CQ8.0Pd/NhG4-E	8.30	1.56	5.32	
GRS-CQ8.0Pd/NhG4-E1	8.00	1.65	4.85	
GRS-CQ10Pd/NhG4-E	10.2	2.00	5.10	230VAC,1Ph,50Hz
GRS-CQ12Pd/NhG4-E	12.0	2.45	4.90	
GRS-CQ14Pd/NhG4-E	13.7	3.00	4.57	
GRS-CQ16Pd/NhG4-E	15.5	3.60	4.31	
GRS-CQ8.0Pd/NhG4-M	8.30	1.64	5.06	
GRS-CQ10Pd/NhG4-M	10.20	2.13	4.79	
GRS-CQ12Pd/NhG4-M	12.0	2.61	4.60	
GRS-CQ14Pd/NhG4-M	13.9	3.32	4.19	400VAC,3Ph,50Hz
GRS-CQ16Pd/NhG4-M	15.4	4.05	3.80	

Notes

- (a) *: Capacities and power inputs are based on the following conditions:

 Entering/leaving Water Temperature 30°C/35°C, Outdoor Air Temperature 7°C DB/6°C WB;
- (b) **:Capacities and power inputs are based on the following conditions:

 Entering/leaving Water Temperature 23°C/18°C, Outdoor Air Temperature 35°C DB/24°C WB.


Mode	Heat Source Side Temperature (°C)	User Side Temperature (°C)
Heating	-25~35	20~65
Cooling	-15~48*	5~25
Water Heating	-25~45	40~80

Note: "*" indicates that for units GRS-CQ8.0Pd/NhG3-E1 and GRS-CQ8.0Pd/NhG4-E1 the heat source side temperature ranges from 10°C to 48°C for cooling.



4. Installation Example


CASE 1: Connecting Under-floor Coil for Heating and Cooling



Notes

- (a) The type and specification of the thermostat should be complied with what specified in this manual;
- (b) The by-pass valve must be installed to secure enough water flow rate, and should be installed at the collector.

CASE 2: Connecting Sanitary Water Tank and Under-floor Coil




Notes

- (a) In this case, the three-way valve should be installed in accordance with what specified this manual;
- (b) The sanitary water tank should be equipped with an internal electric heater to secure enough heat energy in the very cold days.



CASE 3: Connecting Sanitary Water Tank, Under-floor Coil and FCU



Note

The two-way valve is very important to prevent dew condensation on the floor and radiator under the cooling mode.

5. Main Components







6. Installation Guideline of Monobloc Unit

6.1 Instruction to installation

- (1) Installation of the unit must be in accordance with national and local safety codes.
- (2) Installation quality will directly affect the normal use of the air conditioner unit. The user is prohibited from installation. Please contact your dealer after buying this machine. Professional installation workers will provide installation and test services according to installation manual.
- (3) Do not connect to power until all installation work is completed.

6.2 Installation of monobloc unit

6.2.1 Selection of installation location of monobloc unit

- (1) Monobloc unit must be installed on a firm and solid support.
- (2) Avoid placing the monobloc unit under window or between two constructions, hence to prevent normal operating noise from entering the room.
- (3) Air flow at inlet and outlet shall not be blocked.
- (4) Install at a well-ventilated place, so that the machine can absorb and discharge sufficient air.
- (5) Do not install at a place where flammable or explosive goods exist or a place subject to severe dust, salty fog and polluted air.



6.2.2 Outline dimension of monobloc unit








Diagram of Fixing Holes






Description:

Unit: mm

Model	А	В	С	D	E	F
4/6kW	1150	365	750	415	1063	302
8kW-E1	1150	365	750	415	1063	302
8/10/12/14/16kW	1206	445	880	490	1120	322



6.2.3 Space requirements for installation



Unit	A(mm)	B1(mm)	B2(mm)	C(mm)	H1(mm)	H2(mm)	D(mm)	E(mm)	
4~16kW	>2000	>1000	>200	>400	>500	>200	>200	>500	

Notes:

- (1) For areas with frequent snowfall, please clean up the snow in time to avoid covering unit.
- (2) The unit is installed in areas expecting snow are suggested to be raised with support frames.
- (3) If possible, avoid locations that are likely to accumulate snow. If not possible, a snow guard should be installed on the unit to prevent accumulation of snow on the top of the unit.
- (4) Height of the installation foundation should be higher than the height of the annual average snallfall.
- (5) Snow and other litters shall be removed within at least one meter distance from the unit so as to keep the unit in normal operation.



6.2.4 Precautions on installation of monobloc unit

- (1) When moving outdoor unit, it is necessary to adopt 2 pieces of long enough rope to hand the unit from 4 directions. Included angle between the rope when hanging and moving must be 40° below to prevent center of the unit from moving.
- (2) Adopt M12 bolts components to tighten feet and under frame when installing.
- (3) Monobloc unit should be installed on concrete base that is 20cm height.
- (4) Requirements on installation space dimension of unit's bodies are shown in following drawing.
- (5) Monobloc unit must be lifted by using designated lifting hole. Take care to protect the unit during lift. To avoid rusting, do not knock the metal parts.

6.2.5 Usage of rubber rings



- (1) Take away the original rubber rings, replace the long tail rubber rings of accessory;
- (2) Wires installed by field supply get through the rubber rings, such as 2-way valve, 3-way valve, power cable and so on. Be careful of separating electrical wire and light current wire.
- (3) Tie the rubber rings after finishing wire connection.

6.2.6 Safety operation of flammable refrigerant

(1) Qualification requirement for installation and maintenance

All the work men who are engaging in the refrigeration system should bear the valid certification awarded by the authoritative organization and the qualification for dealing with the refrigeration system recognized by this industry. If it needs other technician to maintain and repair the appliance, they should be supervised by the person who bears the qualification for using the flammable refrigerant.

It can only be repaired by the method suggested by the equipment's manufacturer.

(2) Installation notes

The unit is not allowed to use in a room that has running fire (such as firesource, working coal gas ware, operating heater).

It is not allowed to drill hole or burn the connection pipe.

(3) Maintenance notes

Check whether the maintenance area or the room area meet the requirement.

- It's only allowed to be operated in the rooms that meet the requirement.

Check whether the maintenance area is well-ventilated.

- The continuous ventilation status should be kept during the operation process.

Check whether there is fire source or potential fire source in the maintenance area.

- The naked flame is prohibited in the maintenance area; and the "no smoking" warning board should be hanged. nameplate.

Check whether the appliance mark is in good condition.

- Replace the vague or damaged warning mark.



(4) Welding

If you should cut or weld the refrigerant system pipes in the process of maintaining, please follow the steps as below:

- a. Shut down the unit and cut power supply
- b. Eliminate the refrigerant
- c. Vacuuming
- d. Clean it with N2 gas
- e. Cutting or welding
- f. Carry back to the service spot for welding

The refrigerant should be recycled into the specialized storage tank.

Make sure that there isn't any naked flame near the outlet of the vacuum pump and it's well-ventilated.

(5) Filling the refrigerant

Use the refrigerant filling appliances specialized for R32. Make sure that different kinds of refrigerant won't contaminate with each other.

The refrigerant tank should be kept upright at the time of filling refrigerant.

Stick the label on the system after filling is finished (or haven't finished).

Don't overfilling.

After filling is finished, please do the leakage detection before test running; another time of leak detection should be done when it's removed.

(6) Safety instructions for transportation and storage

Please use the flammable gas detector to check before unload and open the container.


No fire source and smoking.

Do comply with the local rules and laws.

7. Installation of Hydraulic Unit


7.1 Available external static pressure of outlet

(1) GRS-CQ4.0Pd/NhG3-E, GRS-CQ6.0Pd/NhG3-E






(2) GRS-CQ4.0Pd/NhG4-E,GRS-CQ6.0Pd/NhG4-E




 $(3) \ GRS-CQ8.0Pd/NhG3-E, \ GRS-CQ8.0Pd/NhG3-E1, GRS-CQ8.0Pd/NhG3-E1, GRS-CQ10Pd/NhG3-E, \ GRS-CQ8.0Pd/NhG3-M, \ GRS-CQ10Pd/NhG3-M$






 $(4) \ \ GRS-CQ8.0Pd/NhG4-E, GRS-CQ8.0Pd/NhG4-E1, GRS-CQ8.0Pd/NhG4-E1, GRS-CQ10Pd/NhG4-E, GRS-CQ8.0Pd/NhG4-M, GRS-CQ10Pd/NhG4-M$




(5) GRS-CQ12Pd/NhG3-E, GRS-CQ14Pd/NhG3-E, GRS-CQ16Pd/NhG3-E, GRS-CQ12Pd/NhG3-M






(6) GRS-CQ14Pd/NhG4-M, GRS-CQ16Pd/NhG4-M, GRS-CQ12Pd/NhG4-E, GRS-CQ14Pd/NhG4-E, GRS-CQ16Pd/NhG4-E, GRS-CQ12Pd/NhG4-M, GRS-CQ14Pd/NhG4-M, GRS-CQ16Pd/NhG4-M




Note: see the curve above for the maximum external static pressure. The water pump is of variable frequency. And during operation, the water pump will adjust its output based on the actual load.

7.2 Ambient temperature and leaving water temperature upper limit

(1) Water Heating Water temperature/°C 58









Note: the ambient temperature and water temperature should be subject to the actual operation of the unit.

7.3 Water volume and expansion vessel pressure







Notes

- (a) The expansion vessel is 2 liters and 1.5bar pre-pressurized for 4/6kW units; 3 liters and 1.5bar per-pressurized for 8/10/12/14/16kW units;
- (b) Total water volume of 44 liters is default for 4/6kW units and 66 liters for 8/10/12/14/16kW unit; if total water is changed because of installation condition, the pre-pressure should be adjusted to secure proper operation. If the unit is located at the highest position, adjustment is not required;
- (c) Minimum total water volume is 20 liters;
- (d) To adjust pre-pressure, use nitrogen gas by certificated installer.

7.4 The method of calculating the charging pressure of expansion vessel

The method of calculating the charging pressure of expansion vessel needed to be adjusted is as follows.

During installation, if the volume of water system has changed, please check if the pre-set pressure of the expansion vessel needs to be adjusted according to the following formula:

 $P_g = (H/10 + 0.3)$ Bar (H ---the difference between installing location of indoor unit and the highest spot of water system)

Ensure that the volume of water system is lower than the maximum volume required in the above figure. If it exceeds the range, the expansion vessel does not meet the installing requirement.

For 4/6units

Installation height 1	Water volume			
difference	<44L	>44L		
< 12m	Adjustment is not necessary	1. Pre-set pressure needs to be adjusted according to the above formula. 2. Check if the water volume is lower than the maximum water volume. (with help of the above figure)		
> 12m	Pre-set pressure needs to be adjusted according to the above formula. Check if the water volume is lower than the maximum water volume. (with help of the above figure)	The expansion vessel is too small and adjustment is not available.		



For 8/10/12/14/16kW units

Installation height ¹	Water volume			
difference	<66L	>66L		
<12 m	Adjustment is not necessary	Pre-set pressure needs to be adjusted according to the above formula. Check if the water volume is lower than the maximum water volume. (with help of the above figure)		
> 12 m	1. Pre-set pressure needs to be adjusted according to the above formula. 2. Check if the water volume is lower than the maximum water volume. (with help of the above figure)	The expansion vessel is too small and adjustment is not available.		

Notes

- (a) Installation height difference: the difference between installing location of indoor unit and the highest spot of water system; if the indoor unit is located at the highest point of the installation, the installation height difference is considered 0m.
- (b) Example 1: The 16kW unit is installed 5m below the highest spot of water system and the total volume of the water system is 60L.
- (c) Referring to the above figure, it is not necessary to adjust the pressure of the expansion vessel.
- (d) Example 2: The unit is installed on the highest spot of the water system and the total water volume is 100L.
- (e) As the volume of water system is higher than 66L, it is necessary to adjust the pressure of the expansion vessel be lower.
- (f) The formula of calculating pressure

$$P_{g} = (H/10 + 0.3) = (0/10 + 0.3) = 0.3 \text{ Bar}$$

- (g) The maximum volume of the water system is about 118L. As the actual volume of the water system is 100L, the expansion vessel meets the installing requirement.
- (h) Adjust the pre-set pressure of the expansion vessel from 1.5Bar to 0.3Bar.

7.5 Selection of expansion vessel

Formula:

$$v = \frac{c \cdot e}{1 - \frac{1 + p_1}{1 + p_2}}$$

V--- Volume of expansion vessel

C--- Total water volume

P₁--- Pre-set pressure of expansion vessel

P₂-- The highest pressure during running of the system (that is the action pressure of safety valve.)

e---The expansion factor of water (the difference between the expansion factor of the original water temperature and that of highest water temperature.)

Water expansion factor in different temperatures				
Temperature (°C)	Expansion factor e			
0	0.00013			
4	0			
10	0.00027			
20	0.00177			
30	0.00435			
40	0.00782			
45	0.0099			
50	0.0121			
55	0.0145			



Water expansion factor in different temperatures				
Temperature (°C)	Expansion factor e			
60	0.0171			
65	0.0198			
70	0.0227			
75	0.0258			
80	0.029			
85	0.0324			
90	0.0359			
95	0.0396			
100	0.0434			


8. Remote Air Temperature Sensor






Front side

Back side








Notes

- (a) Distance between the indoor unit and the remote air temperature sensor should be less than 15m due to length of the connection cable of remote air temperature sensor;
- (b) Height from floor is approximately 1.5m;
- (c) Remote air temperature sensor cannot be located where the area may be hidden when door is open;
- (d) Remote air temperature sensor cannot be located where external thermal influence may be applied;
- (e) Remote air temperature sensor should be installed where space heating is mainly applied;
- (f) After the remote air temperature sensor is installed, it should be set to "With" through the wired controller so as to set the remote air temperature to the control point.

9. Thermostat

Installation of the thermostat is very similar to that of the remote air temperature sensor.



How to Wire Thermostat

- (1) Uncover the front cover of indoor unit and open the control box;
- (2) Identify the power specification of the thermostat, if it is 220V, find terminal block XT3 as NO.3~6;
- (3) If it is the heating/cooling thermostat, please connect wire as per the figure above.

⚠ NOTE

- 220V power supply can be provided to the thermostat by the Versati III heat pump.
- Setting temperature by the thermostat(heating or cooling) should be within the temperature range of the product;
- For other constrains, please refer to previous pages about the remote air temperature sensor;
- Do not connect external electric loads. Wire 220V AC should be used only for the electric thermostat;
- Never connect external electric loads such as valves, fan coil units, etc. If connected, the mainboard of the unit can be seriously damaged;
- Installation of the thermostat is very similar to that of the remote air temperature sensor.

10. 2-Way Valve

The role of 2-way valve 1 is to control the water flow into the underfloor loop. When "Floor Config" is set to "With" for either cooling or heating operation, it will keep open. When "Floor Config" is set to "Without", it will keep closed. General Information

Туре	Power	Operating Mode	Supported		
NO 2-wire	230V 50Hz ~AC	Closing water flow Ye			
NO 2-wire	230V 30H2 ~AC	Opening water flow Yes			
NC 2-wire	230V 50Hz ~AC	Closing water flow	Yes		
	ZOUV DUMZ ~AC	Opening water flow	Yes		


- (1) Normal Open type. When electric power is NOT supplied, the valve is open. (When electric power is supplied, the valve is closed.)
- (2) Normal Closed type. When electric power is NOT supplied, the valve is closed. (When electric power is supplied, the valve is open.)
- (3) How to Wire 2-Way Valve:

Follow steps below to wire the 2-way valve.

Step 1. Uncover the front cover of the unit and open the control box.



Step 2. Find the terminal block and connect wires as below.



⚠ WARNING

- Normal Open type should be connected to wire (OFF) and wire (N) for valve closing in cooling mode.
- Normal Closed type should be connected to wire (ON) and wire (N) for valve closing in cooling mode.

(OFF): Line signal (for Normal Open type) from PCB to 2-way valve

(ON): Line signal (for Normal Closed type) from PCB to 2-way valve

(N): Neutral signal from PCB to 2-way valve

11. 3-Way Valve

The 3-way valve 2 is required for the sanitary water tank. Its role is flow switching between the under floor heating loop and the water tank heating loop.

General Information


Туре	Power	Operating Mode	Supported
SPDT	2201/ 501 1- 40	Selecting "Flow A" between "Flow A" and "Flow B"	Yes
3-wire 230V 50Hz ~AC	Selecting "Flow B" between "Flow B" and "Flow A"	Yes	

- (1) SPDT = Single Pole Double Throw. Three wires consist of Live1 (for selecting Flow B), and Neutral (for common).
- (2) Flow A means 'water flow from the indoor unit to under floor water circuit'.
- (3) Flow B means 'water flow from the indoor unit to sanitary water tank'.

Follow steps below to wire the 3-way valve:

Follow below procedures Step 1 ~ Step 2.

- Step 1. Uncover front cover of the unit and open the control box.
- Step 2. Find terminal block and connect wires as below.



⚠ WARNING


- The 3-way valve should select water tank loop when electric power is supplied to wire (OFF) and wire (N).
- The 3-way valve should select under floor loop when electric power is supplied to wire (ON) and wire (N).
- (ON): Line signal (Water tank heating) from the main board to the 3-way valve
- (OFF): Line signal (Under floor heating) from the main board to the 3-way valve
- (N): Neutral signal from the main board to the 3-way valve



12. Other Thermal


Other thermal is allowed for the equipment and controlled in such a way that the mainboard will output 230V when outdoor temperature is lower than the set point for startup of the aother thermaluxiliary heat source.

Note: Other thermal and Optional Electric Heater CANNOT be installed at the same time.




Step 2. Electric wiring work

The wiring diagram stuck to the main body of the unit always prevails.



Optional water temperature sensor connecet to AP1 CN16.



Step 3. Wired controller setting

Other thermal should be selected "with" if necessarily from COMMISION \rightarrow FUNCTION, then set switch on (outdoor) temperature and control logic(1/2/3).






13. Optional Electric Heater

Optional electric heater is allowed for the equipment and controlled in such a way when outdoor temperature is lower than the set point for startup of the optional electric heater.

Step 1. Optional electric heater installation


Optional electric heater should be installed with monobloc unit in series. Moreover, an accessory called optional water temperature sensor (5 meter length) shall be installed at the same time. The optional electric heater could be 1 group or 2 group, and only works fo space heating.



Step 2. Wired controller setting

Optional electric heater should be selected "1/2" group if necessary from COMMISION \rightarrow FUNCTION,then set switch on (outdoor)temperature and control logic(1/2).








14. Gate-controller


If there is gate control function, the gate-controller should be wired as shown in the figure below.



15. Charging and Discharging of Refrigerant

The unit has been charged with refrigerant before delivery. Overcharging or undercharging will cause the compressor to run improperly or be damaged. When refrigerant is required to be charged or discharged for installation, maintenance and other reasons, please follow steps below and nominal charged volume on the nameplate.


Discharging: remove metal sheets of the outer casing, connect a hose to the charging valve and then discharge refrigerant.



Notes

- (a) Discharge is allowed unless the unit has been stopped. (Cut off the power and repower it 1 minutes later)
- (b) Protective measures should be taken during discharging to avoid frost bites.
- (c) When discharging is finished, if vacuuming cannot be done immediately, remove the hose to avoid air or foreign matters entering the unit.
- (d) Vacuuming: when discharging is finished, use hoses to connect the charging valve, pressure meter and vacuum pump to vacuum the unit.





Note

When vacuuming is finished, pressure inside the unit should be kept lower than 80Pa for at least 30 minutes to make sure there is no leak. Either charging valve 1 or charging valve 2 can be used for vacuuming.

Charging: when vacuuming is finished and it is certain that there is no leak, charging can be done.

Leak Detection Methods:

- (1) The following leak detection methods are deemed acceptable for systems containing flammable refrigerants.
- (2) Electronic leak detector shall be used to detect flammable refrigerant, but the sensitivity may not be adequate, or may need re-calibration(Detection equipment shall be calibrated in a refrigerant-free area).
- (3) Ensure that the detector is not a potential source of ignition and is suitable for the refrigerant used.
- (4) Leak detection equipment shall be set at a percentage of the LFL of the refrigerant and shall be calibrated to the refrigerant employed and the appropriate percentage of gas (25% maximum) is confirmed.
- (5) Leak detection fluids are suitable for us with most refrigerant but the use of detergents containing chlorine shall be avoided as the chlorine may react with the refrigerant and corrode the copper pipe-work.
- (6) If a leak is suspected, all naked flames shall be removed/extinguished. If a leakage of refrigerant is found which requires brazing, all of the refrigerant shall be recovered from the system, or isolated (by means of shut off valves) in a part of the system remote from the leak. Oxygen free nitrogen (OFN) shall then be purged through the system both before and during the brazing process.

Note

Before and during operation, use an appropriate refrigerant leak detector to monitor the operation area and make sure the technicians can be well aware of any potential or actual leakage of inflammable gas. Make sure the leak detecting device is applicable to inflammable refrigerant. For example, it should be free of sparks, completely sealed and safe in nature.



16. Requirements on Water Quality

Parameter	Parametric value	Unit
pH(25°C)	6.8~8.0	/
Cloudy	< 1	NTU
Chloride	< 50	mg/L
Fluoride	< 1	mg/L
Iron	< 0.3	mg/L
Sulphate	< 50	mg/L
SiO ₂	< 30	mg/L
Hardness(count CaCO ₃)	< 70	mg/L
Nitrate(count N)	< 10	mg/L
Conductance(25°C)	< 300	μs/cm
Ammonia (count N)	< 0.5	mg/L
Alkalinity(count CaCO₃)	< 50	mg/L
Sulfid	Cannot be detected	mg/L
Oxygen consumption	< 3	mg/L
Natrium	< 150	mg/L

Note: when circulation water fails to meet requirements listed in the table above, please add anti-scale composition to keep the unit always in normal operation.

17. Electric Wiring

17.1 Wiring principle

General principles

- (1) Wires, equipment and connectors supplied for use on the site must be in compliance with provisions of regulations and engineering requirements.
- (2) Only electricians holding qualification are allowed to perform wire connection on the site.
- (3) Before connection work is started, the power supply must be shut off.
- (4) Installer shall be responsible for any damage due to incorrect connection of the external circuit.
- (5) Caution --- MUST use copper wires.
- (6) Connection of power cable to the electric cabinet of the unit
- (7) Power cables should be laid out through cabling trough, conduit tube or cable channel.
- (8) Power cables to be connected into the electric cabinet must be protected with rubber or plastic to prevent scratch by edge of metal plate.
- (9) Power cables close to the electric cabinet of the unit must be fixed reliably to make the power terminal in the cabinet free from an external force.
- (10) Power cable must be grounded reliably.



17.2 Specification of power supply wire and leakage switch

Power cable specifications and Leakage switch types in the following list are recommended.

Model Model	Power Supply	Power Supply Air Break Switch	Air Break Switch (Electric heater)	Minimum Section Area of Earth Wire	Minimum Section Area of Earth Wire (Electric heater)	Minimum Section Area of Power Wire	Minimum Section Area of Power Wire (Electric heater)
	V,Ph, Hz	Α	A	mm²	mm²	mm²	mm²
GRS-CQ4.0Pd/NhG3-E		16	16	2.5	2.5	2*2.5	2*2.5
GRS-CQ6.0Pd/NhG3-E		05					
GRS-CQ8.0Pd/NhG3-E1		25				0.4.4	
GRS-CQ8.0Pd/NhG3-E		32		4		2*4	
GRS-CQ10Pd/NhG3-E			32		6		2*6
GRS-CQ12Pd/NhG3-E						0.10	
GRS-CQ14Pd/NhG3-E	230VAC	40		6		2*6	
GRS-CQ16Pd/NhG3-E	1Ph 50Hz						
GRS-CQ4.0Pd/NhG4-E		16		2.5		2*2.5	
GRS-CQ6.0Pd/NhG4-E							1
GRS-CQ8.0Pd/NhG4-E1		25			,	2*4	
GRS-CQ8.0Pd/NhG4-E		32	/	4			
GRS-CQ10Pd/NhG4-E							
GRS-CQ12Pd/NhG4-E						2*6	
GRS-CQ14Pd/NhG4-E		40		6			
GRS-CQ16Pd/NhG4-E							
GRS-CQ8.0Pd/NhG3-M				1.5		4*1.5	
GRS-CQ10Pd/NhG3-M							
GRS-CQ12Pd/NhG3-M	400VAC 3Ph 50Hz		16		1.5		3*1.5
GRS-CQ14Pd/NhG3-M				2.5		4*2.5	
GRS-CQ16Pd/NhG3-M		16					
GRS-CQ8.0Pd/NhG4-M				1.5		4*1.5	
GRS-CQ10Pd/NhG4-M				1.0		7 1.0	
GRS-CQ12Pd/NhG4-M			/		/		/
GRS-CQ14Pd/NhG4-M				2.5		4*2.5	
GRS-CQ16Pd/NhG4-M							

Notes

- (a) Leakage Switch is necessary for additional installation. If circuit breakers with leakage protection are in use, action response time must be less than 0.1 second, leakage circuit must be 30mA.
- (b) The above selected power cable diameters are determined based on assumption of distance from the distribution cabinet to the unit less than 75m. If cables are laid out in a distance of 75m to 150m, diameter of power cable must be increased to a further grade.
- (c) The power supply must be of rated voltage of the unit and special electrical line for air-conditioning.
- (d) All electrical installation shall be carried out by professional technicians in accordance with the local laws and regulations.
- (e) Ensure safe grounding and the grounding wire shall be connected with the special grounding equipment of the building and must be installed by professional technicians.
- (f) The specifications of the breaker and power cable listed in the table above are determined based on the maximum power (maximum amps) of the unit.




- (g) The specifications of the power cable listed in the table above are applied to the conduit-guarded multi-wire copper cable (like, YJV XLPE insulated power cable) used at 40°C and resistible to 90°C (see IEC 60364-5-52). If the working condition changes, they should be modified according to the related national standard.
- (h) The specifications of the breaker listed in the table above are applied to the breaker with the working temperature at 40°C. If the working condition changes, they should be modified according to the related national standard.

17.3 Wiring of Control boards

(1) Main board 1 GRS-CQ4.0Pd/NhG3-E GRS-CQ8.0Pd/NhG3-E GRS-CQ16Pd/NhG3-E GRSCQ14Pd/NhG4-E GRS-CQ12Pd/NhG3-M GRS-CQ10Pd/NhG4-M GRS-CQ8.0Pd/NhG3-E1

GRS-CQ6.0Pd/NhG3-E GRS-CQ10Pd/NhG3-E GRS-CQ8.0Pd/NhG4-E GRS-CQ16Pd/NhG4-E GRS-CQ14Pd/NhG3-M GRS-CQ12Pd/NhG4-M GRS-CQ8.0Pd/NhG4-E1 GRS-CQ4.0Pd/NhG4-E GRS-CQ12Pd/NhG3-E GRS-CQ10Pd/NhG4-E GRS-CQ8.0Pd/NhG3-M GRS-CQ16Pd/ NhG3-M GRS-CQ14Pd/NhG4-M GRS-CQ6.0Pd/NhG4-E GRS-CQ14Pd/NhG3-E GRS-CQ12Pd/NhG4-E GRS-CQ10Pd/NhG3-M GRS-CQ8.0Pd/NhG4-M GRS-CQ16Pd/NhG4-M



Silk Screen	Introduction
X1	Power supply
X2	Power supply
Х3	To the ground
CN3	Communication with the unit
CN1	DC12V for Anode
CN4	Communication with control panel
CN18	Build-in water pump signal(PWM)
CN19	Back-up water pump signal(PWM)-field supply
CN15	20K temperature sensor (inlet water);20K temperature sensor (outlet water);20K temperature sensor (refrigerant liquid line)
CN16	20K temperature sensor (refrigerant vapor line);10K temperature sensor (leaving water for the optional electric heater)




Silk Screen	Introduction
CN9	Water tank temperature sensor
CN8	Remote room temperature sensor
CN28	EVU signal
CN27	SG signal
CN25	Flow switch
CN26	DHW signal
CN24	Gate-control detection
CN23	Detection to welding protection for the water tank electric heater
CN22	Detection to welding protection for the optional electric heater 2
CN21	Detection to welding protection for the optional electric heater 1
CN20	Thermostat
X26	Reserved
X25	Plate heat exchanger anti-freezing
X24	Field supplied water pump
X23	Other thermal by 230VAC
X22	E-heater 2
X21	E-heater 1
X20	E-heater of water tank
X34	Electric three-way valve 2 closed
X33	Electric three-way valve 2 open
X32	Reserved
X31	Field supplied 3-way valve 1
X30	Reserved
X29	Water pump of the water tank
X28	2-way valve 1 is normally closed
X27	2-way valve 1 is normally open



(2) Main board 2 GRS-CQ4.0Pd/NhG3-E GRS-CQ8.0Pd/NhG3-E GRS-CQ16Pd/NhG3-E GRSCQ14Pd/NhG4-E GRS-CQ12Pd/NhG3-M GRS-CQ10Pd/NhG4-M GRS-CQ8.0Pd/NhG3-E1

GRS-CQ6.0Pd/NhG3-E GRS-CQ10Pd/NhG3-E GRS-CQ8.0Pd/NhG4-E GRS-CQ16Pd/NhG4-E GRS-CQ14Pd/NhG3-M GRS-CQ12Pd/NhG4-M GRS-CQ8.0Pd/NhG4-E1 GRS-CQ4.0Pd/NhG4-E GRS-CQ12Pd/NhG3-E GRS-CQ10Pd/NhG4-E GRS-CQ8.0Pd/NhG3-M GRS-CQ16Pd/ NhG3-M GRS-CQ14Pd/NhG4-M GRS-CQ6.0Pd/NhG4-E GRS-CQ14Pd/NhG3-E GRS-CQ12Pd/NhG4-E GRS-CQ10Pd/NhG3-M GRS-CQ8.0Pd/NhG4-M GRS-CQ16Pd/NhG4-M



Silk Screen	Introduction
AC-L	Power supply
N	Power supply
4V	4-way valve
VA-1	E-heater of chassis
HEAT	Electric heating tape
FB	1, 2, 3, 4 signals, 5 power supply to EXV2, pipe electronic expansion valve,1-4 pin: driving impulse output; 5 pin: +12V
FA	1, 2, 3, 4 signals, 5 power supply to EXV1,pipe electronic expansion valve,1-4 pin: driving impulse output; 5 pin: +12V
ENTH_PRESS	Reserve
L_PRESS	Reserve
H_PRESS	5V signal input of pressure sensor 1 pin: GND; 2 pin: signal input; 3 pin:+5V
CN7	Communication between AP1 and AP2;communication cable 2-pin: B,3-pin: A;
CN8	1-pin:12V, 2-pin:B, 3-pin: A, 4-pin: ground, To the control panel,communication cable;
CN9	1-pin:+12V, 2-pin:B;3-pin:A, 4-pin: ground
COM_ESPE2	1-pin:+3.3V, 2-pin:TXD, 3-pin:RXD, 4-pin:ground
COM_ESPE1	1-pin:+3.3V, 2-pin:TXD, 3-pin:RXD, 4-pin:ground
LPP	1-pin: +12V, 3-pin: signal
HPP	1-pin:+12V, 3-pin: signal




Silk Screen	Introduction
CN2	1-pin:+12V, 2-pin: signal
T_SENSOR3	Reserve
CN6	Reserve
T_SENSOR2	1,2: environment; 3,4:discharge; 5,6: suction
T_SENSOR1	1,2: economizer inlet; 3,4: economizer outlet; 5,6:defrost
DC-MOTORO1	1-pin: fan power supply;3-pin: fan GND; 4-pin: +15V; 5-pin: control signal;6-pin: feedback signal
DC-MOTORO0	1-pin: fan power supply; 3-pin: fan GND; 4-pin: +15V; 5-pin:control signal;6-pin:feedback signal
PWR1	310V Supply 310V DC power to the drive

(3) Drive board

GRS-CQ4.0Pd/NhG3-E GRS-CQ8.0Pd/NhG3-E1 GRS-CQ6.0Pd/NhG3-E GRS-CQ8.0Pd/NhG4-E1 GRS-CQ4.0Pd/NhG4-E

GRS-CQ6.0Pd/NhG4-E



Silk Screen	Introduction
DC-BUS1	DC-BUS1 Pin for electric discharge of the high-voltage bar during test
POWER-OUT	Open DC link voltage
+24V	Provide 24V voltage to the main board
L-OUT	Live line output (to the main boards)
N-OUT	Neutral line output (to the main boards)
COMM	Communication interface[1-3.3V,2-RX,3-TX,4-GND]
U	Connector to the compressor phase-U
V	Connector to the compressor phase-V
W	Connector to the compressor phase-W



Silk Screen	Introduction
AC_L	L-OUT Live line input of the main board
N	N-OUT Neutral line input of the main board
E	Grounding line

(4) Drive board

GRS-CQ8.0Pd/NhG3-E

GRS-CQ10Pd/NhG3-E

GRS-CQ10Pd/NhG3-E


GRS-CQ16Pd/NhG3-E

GRS-CQ16Pd/NhG4-E

GRS-CQ16Pd/NhG4-E

GRS-CQ16Pd/NhG4-E

GRS-CQ16Pd/NhG4-E






Silk Screen	Introduction
AC-L	L-OUT Live line input of the filter board
N	N-OUT Neutral line input of the filter board
L1-1	To PFC inductor brown line
L1-2	To PFC inductor white line
L2-1	To PFC inductor yellow line
L2-2	To PFC inductor blue line
COMP	Wiring board (3-pin)(DT-66BO1W-03)(variable-frequency)
COMM	Communication interface[1-3.3V,2-TX,3-RX,4-GND]
DC-BUS	DC-BUS Pin for electric discharge of the high-voltage bar during test
PWR	Power input of the drive board [1-GND,2-18V,3-15V]
DC-BUS1	Pin for electric discharge of the high-voltage bar during test

(5) Drive board GRS-CQ8.0Pd/NhG3-M GRS-CQ16Pd/NhG3-M

GRS-CQ10Pd/NhG3-M GRS-CQ8.0Pd/NhG4-M GRS-CQ16Pd/NhG4-M GRS-CQ12Pd/NhG3-M GRS-CQ10Pd/NhG4-M GRS-CQ14Pd/NhG3-M GRS-CQ12Pd/NhG4-M






Silk Screen	Introduction
W	Connector to the compressor phase-W
U	Connector to the compressor phase-U
V	Connector to the compressor phase-V
R-2	
S-2	Connector to reactor (input)
T-2	
R-1	
S-1	Connector to reactor (input)
T-1	
R	Connector to filter L1-F
S	Connector to filter L2-F
Т	Connector to filter L3-F
COMM1	Reserved
COMM	Communication
CN1	Switch power input



(6) Filter board GRS-CQ8.0Pd/NhG3-E GRS-CQ16Pd/NhG3-E GRSCQ14Pd/NhG4-E

GRS-CQ10Pd/NhG3-E GRS-CQ8.0Pd/NhG4-E GRS-CQ16Pd/NhG4-E GRS-CQ12Pd/NhG3-E GRS-CQ10Pd/NhG4-E GRS-CQ14Pd/NhG3-E GRS-CQ12Pd/NhG4-E




Silk Screen	Introduction
AC-L	Live line input of the main board
N	Neutral line of the power supply for the main board
L-OUT	Live line output of the filter board (to the drive and main boards)
N-OUT	Neutral line output of the filter board (to the drive board)
N-OUT1	Output neutral line
L-OUT1	Output live line
DC-BUS	DC-BUS, the other end to the drive board
E	Screw hole for grounding
E1	Grounding line, reserved



(7) Fiter board GRS-CQ8.0Pd/NhG3-M GRS-CQ16Pd/NhG3-M GRSCQ14Pd/NhG4-M

GRS-CQ10Pd/NhG3-M GRS-CQ8.0Pd/NhG4-M GRS-CQ16Pd/NhG4-M GRS-CQ12Pd/NhG3-M GRS-CQ10Pd/NhG4-M GRS-CQ14Pd/NhG3-M GRS-CQ12Pd/NhG4-M




Silk Screen	Introduction
AC-L1	Input side phase L1 of the whole unit
AC-L2	Input side phase L2 of the whole unit
AC-L3	Input side phase L3 of the whole unit



Silk Screen	Introduction		
N	Input side neutral line of the whole unit		
L1-F			
L2-F	Connect to the power supply input of the drive board		
L3-F			
N-F	Neutral line for power supply to the main control board		
X11	Live line for power supply to the main control board		

17.4 Electric wiring of terminal boards

(1) GRS-CQ4.0Pd/NhG3-E, GRS-CQ6.0Pd/NhG3-E, GRS-CQ4.0Pd/NhG4-E, GRS-CQ6.0Pd/NhG4-E Terminal hoard XT3



Whole unit

power

Electric heater power




(2) GRS-CQ8.0Pd/NhG3-E, GRS-CQ10Pd/NhG3-E, GRS-CQ12Pd/NhG3-E, GRS-CQ14Pd/NhG3-E, GRS-CQ16Pd/NhG3-E, GRS-CQ8.0Pd/NhG4-E, GRSCQ10Pd/NhG4-E, GRS-CQ12Pd/NhG4-E, GRSCQ14Pd/NhG4-E, GRS-CQ16Pd/NhG4-E

Terminal board XT3 3 4 5 6 7 8 19 9 10 19 11 20 12 20 13 21 14 21 18 16 17 18 23 24 23 24 25 26 27 28 29 30 1 2 Gate-controller Other Water pump thermal (OUT) Water tank pump power Pump control Water tank signal (OUT) pump control heating signal Thermostat 3-way valve2 SG signal EVU signal 2-way valve1 3-way valve1 Terminal board XT1 Terminal board XT4 Ν Ν



(3) GRS-CQ8.0Pd/NhG3-E1, GRS-CQ8.0Pd/NhG4-E1



Whole unit

power

Electric heater

power



(4) GRS-CQ8.0Pd/NhG3-M,GRS-CQ10Pd/NhG3-M, GRS-CQ8.0Pd/NhG4-M, GRS-CQ10Pd/NhG4-M, GRS-CQ12Pd/NhG3-M, GRS-CQ14Pd/NhG3-M, GRS-CQ16Pd/NhG3-M, GRS-CQ12Pd/NhG4-M, GRS-CQ14Pd/NhG4-M, GRS-CQ16Pd/NhG4-M

Terminal board XT3 8 19 9 10 19 11 20 12 20 13 21 3 4 5 6 7 14 21 18 16 17 18 23 24 23 24 25 26 Pump control Water tank signal (OUT) pump control heating signal Gate-controller Thermostat 2-way valve1 3-way valve2 3-way valve1 Other thermal Water pump (OUT) Water tank pump power Terminal blockXT1 Terminal blockXT4 L3 2 L1 L2 Ν 3 N(1)



18. Commissioning

18.1 Check before startup

For safety of users and unit, the unit must be started up for check before debugging. The procedures are as below:

pelow:				
The fo	ollowing items shall be performed by qualified repair persons.			
	rm together with the sales engineer, dealer, installing contractor and customers for the following items finished	or to		
	ished.	,		
No.	Confirmation of Installation	√		
1	If the contents of Application for Installation of this Unit by Installer are real. If not, debugging will be refused.			
2	Is there written notice in which amendment items are shown in respect of unqualified installation?			
3	Are Application for Installation and Debugging list filed together?			
No.	Pre-check	√		
1	Is appearance of the unit and internal pipeline system ok during conveying, carrying or installation?			
2	Check the accessories attached with the unit for quantity, package and so on.			
3	Make sure there is drawings in terms of electricity, control, design of pipeline and so on.			
4	Check if installation of the unit is stable enough and there is enough space for operation and repair.			
5	Completely test refrigerant pressure of each unit and perform leakage detection of the unit.			
6	Is the water tank installed stably and are supports secure when the water tank is full?			
7	Are heat insulating measures for the water tank, outlet/inlet pipes and water replenishing pipe proper?			
8	Are the nilometer of water tank, water temperature indicator, controller, manometer, pressure relief valve and automatic discharge valve etc. installed and operated properly?			
9	Does power supply accord with the nameplate? Do power cords conform to applicable requirements?			
10	Is power supply and control wiring connected properly according to wiring diagram? Is earthing safe? Is each terminal stable?			
11	Are connection pipe, water pump, manometer, thermometer, valve etc. are installed properly?			
12	Is each valve in the system open or closed according to requirements?			
13	Confirm that the customers and inspection personnel of Part A are at site.			
14	Is Installation Check-up Table completed and signed by the installation contractor?			
Attent	tion: If there is any item marked with ×, please notify the contractor. Items listed above are just for reference.			
	General Evaluation: Debugging Amendment			
င္ပ	Judge the following items (if there is not any filling, qualification will be regarded.)			
nfirn	a: Power supply and electric control system b: Loading calculation			
ned I	c: Heating problems of Unit d: Noise problem			
tems	e: Pipeline problem f: Others			
Confirmed Items after pre-checking	Normal debugging work can't be performed unless all installation items are qualified. If there is any problem, it must be solved firstly. The installer will be responsible for all costs for delay of debugging and re-debugging incurred by any problem which is not solved immediately.			
checl	Submit schedule of amending reports to installer.			
king	Is the written amending report which should be signed after communication provided to installer?			
	Yes () No ()			



18.2 Test run

Test run is testing whether the unit can run normally via preoperation. If the unit cannot run normally, find and solve problems until the test run is satisfactory. All inspections must meet the requirements before performing the test run. Test run should follow the content and steps of the table below:

The follow	wing procedu	ure should be executed by experience and qualified maintenance men.			
No.	Start up the pretest procedure				
Notice: be casualty.	efore test, er	nsure that all power must be cut off, including the far- end power switch, otherwise, it may cause			
1	Ensure that	at the compressor of the unit is preheated for 8h.			
		lubricating oil at least 8h in advance to prevent refrigerant from mixing with the lubricating oil, which to the compressor when starting up the unit.			
2	Check who	ether the phase sequence of the main power supply is correct. If not, correct the phase sequence			
Reche	eck the phas	e sequence before start-up to avoid reverse rotation of the compressor which may damage the unit.			
3		universal electric meter to measure the insulation resistance between each outdoor phase and earth between phases.			
⚠ Cautio	on: defective	earthing may cause electric shock.			
No.		Ready to start			
	Cut off all	temporary power supply, resume all the insurance and check the electricity for the last time.			
1	Check the operating	power supply and voltage of the control circuit;V must be ±10% within the range of rated power.			
No.		Start up the unit			
1	Check all	Check all the conditions needed to start up the unit: operation mode, required load etc.			
	Start up th	e unit, and observe the operation of compressor, electronic expanding valve, fan motor and water			
2	Note: the	unit will be damaged under abnormal running state. Do not operate the unit in states of high and high current.			
Others:					
		Estimation or suggestion on the general running situation: good, modify			
		Identify the potential problem (nothing means the installation and commissioning are in			
		accordance with the requirements.)			
Items for acceptance after commissioning		a. problem of power supply and electric control system:			
		b. problem of load calculation:			
		c. outdoor refrigerant system:			
		d. noise problem:			
		e. problem of indoor and piping system:			
		h. other problems: During operation, it is needed to charge for the maintenance due to non-quality problems such as			
		incorrect installation and maintenance.			
		Acceptance			
	Is the user trained as required? Please sign. Yes() No()				

19. Daily Operation and Maintenance

In order to avoid damage of the unit, all protecting devices in the unit had been set before delivery, so please do not adjust or remove them.

For the first startup of the unit or next startup of unit after long-period stop (above 1 day) by cutting off the power, please electrify the unit in advance to preheat the unit for more than 8 hours.



Never put sundries on the unit and accessories. Keep dry, clean and ventilated around the unit.

Remove the dust accumulated on the condenser fin timely to ensure performance of the unit and to avoid stop of the unit for protection.

In order to avoid protection or damage of the unit caused by blockage of the water system, clean the filter in water system periodically and frequently check water replenishing device.

In order to ensure anti-freezing protection, never cut off the power if ambient temperature is below zero in winter. In order to avoid frost crack of the unit, water in the unit and pipeline system not used for a long period should be drained. In addition, open the end cap of the water tank for drainage.

When the water tank has been installed but the water tank is set to "Without", functions relative with the water tank will not work and the displayed water tank temperature will always be "-30". In this case, the water tank would suffer frostbite and even other severe influences under low temperature. Therefore, once the water tank has been installed, the water tank must be set to "With", otherwise will will not be responsible for this abnormal operation.

Never frequently make the unit on/off and close the manual valve of the water system during operation of the unit by users.

Ensure frequent check to the working condition of each part to see if there is oil stain at pipeline joint and charge valve to avoid leakage of refrigerant.

If malfunction of the unit is out of control of users, please timely contact with authorized service center.

Notes

The water pressure gage is installed in the returning water line in the unit. Please adjust the hydraulics system pressure according to next item:

- (1) If the pressure is less than 0.5 bar, please recharge the water immediately.
- (2) When recharging, the hydraulics system pressure should be not more than 2.5 Bar.

Malfunctions	Reasons	Troubleshooting	
Compressor does not start up	Power supply has problem. Connection wire is loose. Malfunction of mainboard. Malfunction of compressor.	Phase sequence is reverse. Check out and re-fix. Find out the reasons and repair. Replace compressor.	
Heavy noise of fan	Fixing bolt of fan is loose. Fan blade touches shell or grill. Operation of fan is unreliable.	Re-fix fixing bolt of fan. Find out the reasons and adjust. Replace fan.	
Heavy noise of compressor	Liquid slugging happens when liquid refrigerant enters into compressor. Internal parts in compressor are broken.	Check if expansion valve is failure and temp. sensor is loose. If that, repair it. Replace compressor.	
Water pump does not run or runs abnormally	Malfunction of power supply or terminal. Malfunction of relay. There is air in water pipe.	Find out the reasons and repair. Replace relay. Evacuate.	
Compressor starts or stops frequently	Poor or excess refrigerant. Poor circulation of water system. Low load.	Discharge or add part of refrigerant. Water system is blocked or there is air in it. Check water pump, valve and pipeline. Clean water filter or evacuate. Adjust the load or add accumulating devices.	
The unit does not heat although compressor is running	Leakage of refrigerant. Malfunction of compressor.	Repair by leakage detection and add refrigerant. Replace compressor.	
Poor efficiency of hot water heating	Poor heat insulation of water system. Poor heat exchange of evaporator. Poor refrigerant of unit. Blockage of heat exchanger at water side.	Enhance heat insulation efficiency of the system. Check if air in or out of unit is normal and clean evaporator of the unit. Check if refrigerant of unit leaks. Clean or replace heat exchanger.	



19.1 Recovery

When removing refrigerant from a system, either for servicing or decommissioning, it is recommended good practice that all refrigerants are removed safely.

When transferring refrigerant into cylinders, ensure that only appropriate refrigerant recovery cylinders are employed. Ensure that the correct number of cylinders for holding the total system charge are available. All cylinders to be used Ensure that the correct number of cylinders for holding the total system charge are available. All cylinders to be used are designated for the recovered refrigerant and labelled for that refrigerant (i.e. special cylinders for the recovery of refrigerant). Cylinders shall be complete with pressure relief valve and associated shut-off valves in good working order. Empty recovery cylinders are evacuated and, if possible, cooled before recovery occurs.

The recovery equipment shall be in good working order with a set of instructions concerning the equipment that is at hand and shall be suitable for the recovery of flammable refrigerants.

In addition, a set of calibrated weighing scales shall be available and in good working order.

Hoses shall be complete with leak-free disconnect couplings and in good condition. Before using the recovery machine, check that it is in satisfactory working order, has been properly maintained and that any associated electrical components are sealed to prevent ignition in the event of a refrigerant release. Consult manufacturer if in doubt.

The recovered refrigerant shall be returned to the refrigerant supplier in the correct recovery cylinder, and the relevant Waste Transfer Note arranged. Do not mix refrigerants in recovery units and especially not in cylinders.

If compressors or compressor oils are to be removed, ensure that they have been evacuated to an acceptable level to make certain that flammable refrigerant does not remain within the lubricant. The evacuation process shall be carried out prior to returning the compressor to the suppliers. Only electric heating to the compressor body shall be employed to accelerate this process. When oil is drained from a system, it shall be carried out safely.

19.2 Decommissioning

Before carrying out this procedure, it is essential that the technician is completely familiar with the equipment and all its detail. It is recommended good practice that all refrigerants are recovered safely. Prior to the task being carried out, an oil and refrigerant sample shall be taken in case analysis is required prior to re-use of reclaimed refrigerant. It is essential that electrical power is available before the task is commenced.

- a) Become familiar with the equipment and its operation.
- b) Isolate system electrically.
- c) Before attempting the procedure ensure that: mechanical handling equipment is available, if required, for handling refrigerant cylinders; all personal protective equipment is available and being used correctly; the recovery process is supervised at all times by a competent person; recovery equipment and cylinders conform to the appropriate standards.
 - d) Pump down refrigerant system, if possible.
- e) If a vacuum is not possible, make a manifold so that refrigerant can be removed from various parts of the system.
 - f) Make sure that cylinder is situated on the scales before recovery takes place.
 - g) Start the recovery machine and operate in accordance with manufacturer's instructions.
 - h) Do not overfill cylinders. (No more than 80 % volume liquid charge).
 - i) Do not exceed the maximum working pressure of the cylinder, even temporarily.
- j) When the cylinders have been filled correctly and the process completed, make sure that the cylinders and the equipment are removed from site promptly and all isolation valves on the equipment are closed off.
- k) Recovered refrigerant shall not be charged into another refrigeration system unless it has been cleaned and checked.



19.3 Notice before seasonal use

- (1) Check whether air inlets and air outlets of indoor and outdoor units are blocked
- (2) Check whether ground connection is reliable or not
- (3) If unit starts up after not operating for a long time, it should be power on 8 hours before operation starts so as to preheat the outdoor compressor
- (4) Precautions for Freeze Protection in Winter

Under subzero climatic conditions in winter, anti-freeze fluid must be added into the water cycle and external water pipes should be properly insulated. Glycol solution is recommended as the anti-freeze fluid.

Concentration	Freezing Temp	Concentration	Freezing Temp	Concentration	Freezing Temp
%	°C	%	°C	%	°C
4.6	-2	19.8	-10	35	-21
8.4	-4	23.6	-13	38.8	-26
12.2	-5	27.4	-15	42.6	-29
16	-7	31.2	-17	46.4	-33

Note: "Concentration" listed in the table above indicates the mass concentration.

19.4 Error Codes

(1) Complete unit code

Code Indication Error Name		Source of Error Signal	Control Description
F4	Outdoor environment temp sensor error	 The plug on temperature sensor is not correctly connected to the socket on mainboard. The resistance of temperature sensor is not correct. 	It will be automatically cleared after the failure is removed.
d6	Defrost temp sensor error	 The plug on temperature sensor is not correctly connected to the socket on mainboard. The resistance of temperature sensor is not correct. 	It will be automatically cleared after the failure is removed.
F7	Discharge temp sensor error	 The plug on temperature sensor is not correctly connected to the socket on mainboard. The resistance of temperature sensor is not correct. 	It will be automatically cleared after the failure is removed.
F5	Suction temp sensor error	 The plug on temperature sensor is not correctly connected to the socket on mainboard. The resistance of temperature sensor is not correct. 	It will be automatically cleared after the failure is removed.
EF	Outdoor fan error	 Mainboard of outdoor unit is damaged. The wire connecting the wiring terminals of the mainboard breaks. 	If it occurs for 6 times during one hour, it is cleared by deenergization. If it occurs for less than 6 times, it will be automatically cleared.



Code Indication	Error Name	Source of Error Signal	Control Description
E1	Comp High-pressure protection	 Comp High-pressure switch is broken or the wiring is loose. The water in the tank is not enough. The installation of tank temp sensor is not correct. The gas valve and liquid valve are not fully open. The electronic expansion valve can not work normally. 	De-energize the unit and then, energize it again. If the malfunction is removed, the code will be cleared.
E3	Comp Low- pressure protection	Comp Low-pressure switch is broken or the wiring is loose. The system has leaked. The fans stop running or reverse.	It will be cleared if the malfunction is removed after the unit has been turned off.
E4	Comp Discharge temp protection	The resistance of temperature sensor is not correct. The electronic expansion valve is blocked. The system has leaked. Mainboard of outdoor unit is damaged.	It will be cleared if the discharge temp is lower than 92°C.
C5	Cpacity switch error	① The jumper trips off.	De-energize the unit and then energize it again. If the malfunction is removed, the code will be cleared.
E6	Communication malfunction(between outdoor and indoor mainboard0.	The communication line of the unit is not connected. The communication line is not through. The communication line of the unit is not connected correctly. The two ends of communication line are not mounted with magnetic ring. The outdoor unit is not electrically powered	It will be cleared once communication recovers or it will be shown all the time
E 6	Communication malfunction(between outdoor mainboard and wired controller)	The communication line of the unit is not connected. The communication line is not through. The communication line of the unit is not connected correctly. The two ends of communication line are not mounted with magnetic ring. The outdoor unit is not electrically powered	It will be cleared once communication recovers or it will be shown all the time



Code Indication	Error Name	Source of Error Signal	Control Description
Fc	High pressure switch error	The sensor is damaged. The wire of the sensor is loose. The position of the sensor is wrong	It will be automatically cleared after the failure is removed.
F9	Outlet temperature sensor error	The plug on temperature sensor is not correctly connected to the socket on mainboard. The resistance of temperature sensor is not correct.	It will be automatically cleared after the failure is removed.
dH	Backup outlet temperature sensor error	The plug on temperature sensor is not correctly connected to the socket on mainboard. The resistance of temperature sensor is not correct.	It will be automatically cleared after the failure is removed.
F1	Lliquid pipe temperature sensor Inside refrigerant error	 The plug on temperature sensor is not correctly connected to the socket on mainboard. The resistance of temperature sensor is not correct. 	It will be automatically cleared after the failure is removed.
FE	The first sanitary water tank temperature sensor error	The plug on temperature sensor is not correctly connected to the socket on mainboard. The resistance of temperature sensor is not correct.	It will be automatically cleared after the failure is removed.
F3	Gas pipe temperature sensor inside refrigerant error	The plug on temperature sensor is not correctly connected to the socket on mainboard. The resistance of temperature sensor is not correct.	It will be automatically cleared after the failure is removed.
F0	Remote room temperature sensor error	The plug on temperature sensor is not correctly connected to the socket on mainboard. The resistance of temperature sensor is not correct.	It will be automatically cleared after the failure is removed.
Ec	Water switch error	 The switch is damaged. The wire of the switch is loose. The position of the switch is wrong 	It will be cleared after the unit is turned off.
E2	Indoor anti-frozen protetion	The resistance of temperature sensor is not correct. The electronic expansion valve can not work normally.	It will be cleared once malfunction is removed or it will be shown all the time; but it will be cleared immediately when switching operation mode.




Code Indication	Error Name	Source of Error Signal	Control Description
Ed	outlet temperature High- temp protection	The resistance of temperature sensor is not correct. The plug on temperature sensor is not correctly connected to the socket on mainboard. Mainboard of outdoor unit is damaged.	De-energize the unit and then, energize it again. If the malfunction is removed, the code will be cleared.
EH	the first internal electric heater connection Malfunction	① The AC contactor is damaged.	De-energize the unit and then, energize it again. If the malfunction is removed, the code will be cleared.
EH	second internal electric heater connection Malfunction	① The AC contactor is damaged.	De-energize the unit and then, energize it again. If the malfunction is removed, the code will be cleared.
EH	sanitary water tank electric heater connection Malfunction	① The AC contactor is damaged.	De-energize the unit and then, energize it again. If the malfunction is removed, the code will be cleared.



(2) Drive failure code

Item		Display on Nixie Tube of the Unit	Display on Wired Controller	Others
	Reset of Drive System	P0	Reset of Drive System	
	Startup Failure of Compressor	Lc	Startup Failure of Compressor	
	Phase Protection	Ld	Phase Protection	
	Current protection of compressor	P5	Current protection of compressor	
	Communication failure	P6	Communication failure	
	Sensor failure of heat sink	P7	Sensor failure of heat sink	
	Overheat protection of heat sink	P8	Overheat protection of heat sink	
	AC current protection (input side)	PA	AC current protection (input side)	
Inverter Drive Failure	Current sensor failure	Pc	Current sensor failure	
	Connection protection of sensor	Pd	Connection protection of sensor	
	Overvoltage protection	PH	Overvoltage protection	
	Under-voltage protection	PL	Under-voltage protection	
	Abnormality of input AC voltage	PP	Abnormality of input AC voltage	
	Charge circuit failure	PU	Charge circuit failure	
	IPM protection	H5	IPM protection	
	Desynchronizing of motor	H7	Desynchronizing of motor	
	PFC abnormality	Hc	PFC abnormality	





GREE ELECTRIC APPLIANCES, INC. OF ZHUHAI

Add: West Jinji Rd, Qianshan, Zhuhai, Guangdong, China, 519070

Tel: (+86-756) 8522218 Fax: (+86-756) 8669426

E-mail: global@cn.gree.com www.gree.com

